



USER GUIDE

Automatic movement
crown screwed



Your B.R.M Chronographes watch was manufactured, assembled and checked with the utmost care by our watch-makers.

To ensure longevity please read the following instructions carefully.

Time setting

Your watch has a 38-hours power reserve approximately. If the watch is not worn daily the power reserve will run out and the watch will stop.

To set the time, please unscrew (A) your crown and pull it to position 3.

After setting the time, return the crown to 0 by pressing and turning it to the screw without forcing (B).

Date setting

Shaft winder in position 2.



Reset

After a long stop of use, turn the crown 5 or 6 times to position 1.

The movement starts to run again.

Second hand

Date



Water resistance

All B.R.M Chronographes watches are waterproof. The indication of the water resistance level is engraved on the back of the watch. This indication correspond to the current norms of the watchmaking industry. The measurements have been carried out by application of pressure and underpressure.

The maintenance of the waterproof characteristics of your watch depends on the care you will bring.

Never activate any button or corrector while in water. Before any contact with liquids, make sure the winder is in position 0.

Safety Instructions

Your B.R.M Chronographes watch is a precision tool. It is important not to expose it to:

- magnetic fields,
- very sudden temperature changes,
- after sea use, rinse it out with tepid water.

Maintenance

The maintenance or repair of your B.R.M Chronographes watch must be carried out exclusively by a B.R.M Chronographes authorized dealer.

brm-chronographes.com

