



USER GUIDE

Automatic movement
R46 or R50
crown screwed



Your B.R.M Chronographes watch was manufactured, assembled and checked with the utmost care by our watch-makers.
To ensure longevity please read the following instructions carefully.

The watch, with its innovating mechanism, is made of a wind up rotor with tantalum weights.

The movement, suspended by fiber triangles (carbon or fiberglass) is fixed inside the box by a BRM's patented system technology (Isolastic®).

All the movement's screws were replaced by bolts.



Time setting

Your automatic watch has an approximate 48 extra working hours.

If the watch is not worn daily, the extra hours will run out and the watch will stop.

To set the time, please unscrew (A) your crown and pull it to position 3.

Position 2 on your crown is neutral.

After setting the time, return the crown to 0 by pressing and turning it to screw without forcing (B).

Winding on


After a long time not worn, please unscrew (A) your crown, pull it to position 1 and turn the crown 5 or 6 times.

The movement starts running again.

After winding on, return the crown to by pressing and turning it to screw without forcing (B).

Power reserve hands

- position 0: your movement is stopped
 - position 48: you have a 48H autonomy
- If you do not wear your watch for 24H, you have a 24H autonomy.



Water-resistance

All B.R.M Chronographes watches are waterproof. The indication of the water-resistance level in meters is engraved on the back of the case. This indication corresponds to the current norms of the watch-making industry. The measurements have been carried out by application of pressure and depression. The maintenance of the waterproof characteristics of your watch depends on the care you will bring.

Never activate any button or corrector while in water. Before any contact with liquids, make sure the winder is in position 0.

Safety Instructions

Your B.R.M Chronographes watch is a precision tool. It is important not to expose it to:

- strong vibrations,
- magnetic fields,
- very sudden temperature changes,
- after sea use, rinse it out with tepid water.

Maintenance

The maintenance or repair of your B.R.M Chronographes watch must be carried out exclusively by a B.R.M Chronographes authorized dealer.

brm-chronographes.com

